


极思新材料 CMP Slurry Introduction

2023. 08

极思新材料 Silica Slurry Features



- Excellent abrasive dispersity
- Long-term storage stability
- Cation freely controllable


- Low solid contents – High Ox removal rate
Low defect/Scratch
- Low Si₃N₄ removal rate
High quality surface, High Ox/SiN selectivity

02 R&D Roadmap

Silica Slurry R&D Road Map

Confidential

- **Fine Surface product line** : SW-300, SW-350 at W buffing, Carbon/ACL at Organic film
- **High Removal Rate product Line** : W & Cu Bulk CMP Slurry, High Removal Rate at TSV Process
- **Selectivity Control Product Line** : SW-200 at W Barrier, HPR-100 at Cu Barrier, STM-210 at TSV Hybrid



03 Major Product Portfolio

Silica Slurry Product Portfolio

Confidential

Product			Properties	Advantages
Silica-Based	W Bulk	SW-100	- W = 3000~4000 Å/min	High dilution ratio x10
	W BM W buffing	SW-200 SW-300	- W = ~200 Å/min, Ox = 1000 Å/min - W = 20~40 Å/min	Low price & low defects
	Cu Barrier	HPR-100 SD-200	- Cu = 300~700 Å/min, Ta = ~500 Å/min - Ox = 1000~1400 Å/min	Low trace metal (low defects)
	Poly-Silicon	SPS-100	- Poly-Si = 3000~4000 Å/min - Ox = <50 Å/min	Low dishing at wide pattern
	TSV	STM-210 HTSV-100 ST-500	- Cu = 1000~3000 Å/min - Ox = 1000~4500 Å/min - SiN = 50~2500 Å/min	High Removal rate Good surface quality
	Carbon / ACL	SAC-100	- Low defect, Planarization Efficiency ↑ - Carbon High Removal Rates	
	Nitride	NTS-300 (极思-CE-10)	- Nit = 600~900 Å/min - Poly-Si/Ox = 10 Å/min ↓	High removal rate SiN Low defects

03 Major Product Portfolio


Product_W Slurry

Confidential

◆ Tungsten Slurry

- Tungsten bulk & barrier process in a damascene architecture
- Lower defect levels and higher yields
- Lower Cost-of-Ownership

ITEM	SW-100	SW-200	SW-300	SW-300B2
Abrasive	CS*	CS	CS	HPCS*
Particle Size by DLS	120nm	42nm	42 nm	120 nm
pH	Acidic	Acidic	Acidic	Acidic
Solid Content (Only abrasive)	3.5 wt%	0.1~1 wt%	3.0 wt%	3.5 wt%
Surface charge	Negative	Positive	Positive	Negative
W RR	3000~4000	3000~4000	200~300	200~500
Ox RR	800~1000	15~30	1000~1200	800~1000
H2O2(%)	2.8	2.8	0.5	0.5
Application	W bulk CMP		W/SiO2 CMP	



1) W bulk CMP condition → Polisher : AP-300, Pad : 极思 HD-319B, W/P: 3.2/3.0/3.0/3.0/3.0 psi, R-Ring : 10.5 psi, Head/Table: 100/101 rpm, Slurry : 250 ml/min

2) W/SiO2 CMP condition → Polisher : AP-300, Pad : 极思 HD-319B, W/P: 1.0/1.0/1.0/1.0/1.0 psi, R-Ring : 3.0 psi, Head/Table: 100/101 rpm, Slurry : 250 ml/min

3) W/SiO2 B2 CMP condition → Polisher : AP-300, Pad : IC1010, W/P: 3.7/3.5/3.5/3.5/3.5 psi, R-Ring : 8.5 psi, Head/Table: 100/101 rpm, Slurry : 250 ml/min

* CS : Colloidal Silica, HPCS : High Purity Colloidal Silica

03 Major Product Portfolio




Product_Cu Barrier Slurry

Confidential

◆ Cu Barrier Metal Slurry


- Defect reduction by special chemical treatment & pure silica
- Tunable Cu/Ta/Ox removal rates

◆ Basic Properties & Performances

ITEM	Competitor	HPR-100	SD-200
Abrasive	CS	HPCS	CS
TEM Images			
Particle Size by DLS	86nm	67nm	81nm
pH	Basic	Basic	Basic
Solid Content (Only abrasive)	14~16 wt%	8~10 wt%	14~16 wt%
Zeta potential(mV)	Negative	Negative	Negative

* CS : Colloidal Silica, HPCS : High Purity Colloidal Silica

◆ CMP Test Results & Selectivity



Polisher : AP-300, Pad : Fujibo pad, W/P: 5.5/2.2/2.4/2.2/2.1 psi,
R-Ring : 6.3 psi, Head/Table: 103/97 rpm, Slurry : 270 ml/min

◆ Defect Analysis Results

Defects(ea)	Competitor	HPR-100	SD-200
Ox blanket wafer	159	63	64
Cu blanket wafer	1303	704	671
MIT Pattern wafer	1893	925	1035

* Inspection : KLA Tencor AIT-XP+

03 Major Product Portfolio



Product_Poly-Silicon Slurry

Confidential


◆ Poly-Silicon Slurry

- Special chemical treatment at Poly-Silicon
- High selectivity Poly-Si/Ox or SiN films
- Low dishing at wide range Poly-Si patterns

◆ Basic Properties & Performances


ITEM	Competitor	SPS-100
Abrasive	HPCS	HPCS
SEM Images		
Particle Size by DLS	133nm	129nm
pH	Basic	Basic
Solid Content (Only abrasive)	3~4 wt%	2~3 wt%
Viscosity(cps)	1.2 ~ 1.3	1.2 ~ 1.3

◆ CMP Test Results & Selectivity



Polisher : AP-300, Pad : 极思 HD-319B, W/P: 4.0/2.5/2.5/2.5/2.5 psi,
R-Ring : 6.5 psi, Head/Table: 103/97 rpm, Slurry : 300 ml/min

◆ 300mm Profile



03 Major Product Portfolio


Product_Nitride Slurry

Confidential


◆ Nitride Slurry

- Excellent selectivity (High Removal Nitride)
- Low Oxide dishing
- 3D-NAND application

◆ Basic Properties & Performances

ITEM	NTS-300
Abrasive	CS
SEM Images	
Particle Size by DLS	35nm
pH	Acidic
Solid Content	8~10 wt%
Zeta potential(mV)	Negative
Slurry : DIW rate	1:1 ~ 1:3 mixing

◆ CMP Test Results & Selectivity



Polisher : AP-300, Pad : 极思 HD-319B, W/P: 4.5/2.1/2.1/2.1/2.15 psi, R-Ring : 6.5 psi, Head/Table: 63/59 rpm, Slurry : 300 ml/min

CMP Performances	Data
Nitride R/R (Å/min.)	700~900
Selectivity	Oxide : Poly : Nitride 1 : 1 : 15~20
Uniformity (Å)	46~73 Å
cell center-edge deviation (Å)	Edge : ~16 Å Middle : ~24 Å Center : ~21 Å
Dishing & Dent	none
Ox blanket defects	<100 ea
3D NAND PW defects	8~63 ea
Shelf life (month)	12 month

03 Major Product Portfolio

Product_ACL Slurry


Confidential

◆ ACL Slurry

- High R/R(various removal rates of SAC-100)
- Lower defect levels and higher yields
- Pad contamination free

◆ Concept of SAC-100


Abrasive
<ul style="list-style-type: none">▪ Abrasive Size Optimization▪ Pad Contamination Improvement
Accelerator
<ul style="list-style-type: none">▪ ACL Removal Rate Enhancer<ul style="list-style-type: none">▪ Defect ↓
Stabilizer
<ul style="list-style-type: none">▪ Effects of Metal Chelating▪ Improved Satability of Accelerator
Surfactant
<ul style="list-style-type: none">▪ Increase Wettability▪ Residual & Defect ↓

ITEM	SAC-100
Abrasive	CS
SEM Images	
Particle Size by DLS	45nm
pH	Acidic
Solid Content	3 ~ 6 wt%



Pad contamination free

Polisher : AP-300, Pad : 极思 HD-319B, W/P: 4.0/2.0/2.0/2.0/2.0 psi,
R-Ring : 5.17 psi, Head/Table: 87/93 rpm, Slurry : 200 ml/min



- SAC-100(A) : High R/R, Good Defect
- SAC-100(B) : Advanced Roughness, Long Lifetime

03 Major Product Portfolio


Product_TSV Cu Slurry

Confidential


◆ TSV Cu Slurry

- Cu RR range = 800 ~ 5,500 Å/min
- Ox RR range = 200 ~ 3,900 Å/min
- Controllable Cu & Ox RR with selectivity
- Acidic type

◆ Basic Properties & Performances

ITEM	HTSV-100
Abrasive	CS
TEM Images	
Particle Size by DLS (nm)	42
pH	Acidic
Solid Content (wt%)	7.5 ~ 15
Zeta potential(mV)	Positive

◆ CMP Test Results & Selectivity



[CMP condition]

H₂O₂ (wt%)

Polisher : AP-300 / Pad : 极思-HD-319B, Pressure: 5.5/3.0/3.0/3.3/3.0,
R-Ring : 8.0 psi, Carrier/Platen: 117/120 rpm, SFR: 300 ml/min

◆ Slurry Performance

H ₂ O ₂ (%)	Removal rates (Å/min)			Selectivity		
	Cu	SiN	Ox	Ox/SiN	Ox/Cu	SiN/Cu
0.10	1343	1243	3410	2.74	2.54	0.93
0.25	3413	1366	3809	2.79	1.12	0.40
0.50	4476	1322	3811	2.88	0.85	0.30
0.75	3742	1342	3668	2.73	0.98	0.36
1.00	3280	1298	3744	2.88	1.14	0.40

03 Major Product Portfolio


Product_TSV HRR Slurry

Confidential


◆ TSV HRR Slurry

- High Ox Removal Rate
- High Selectivity(Ox/SiN selectivity >11)
- Controllable Cu & SiN RR


◆ Basic Properties & Performances

ITEM	HTSV-100
Abrasive	CS
TEM Images	
Particle Size by DLS (nm)	45
pH	Acidic
Solid Content (wt%)	15
Zeta potential(mV)	Positive

◆ Slurry Performance



◆ CMP Test Results & Selectivity



03 Major Product Portfolio


Product_TSV Advanced Slurry

Confidential


◆ TSV Advanced Slurry

- High Removal Rates & Low Defect
- Controllable Cu & Ox RR with selectivity
- TSV Hybrid & New concept target slurry

◆ Basic Properties & Performances


ITEM	STM-210	ST-500
Abrasive	Colloidal Silica	
SEM Images		
Particle Size by DLS	45nm	
pH	4.1	4.1
Solid Content (Only abrasive)	15 wt%	5 wt%
Zeta-potential	< +20 mV	
Conductivity	< 1 mS/cm	< 1 mS/cm

◆ Hybrid Slurry CMP Test Results(STM-210)



Polisher : AP-300, Pad : IC1010, W/P: 3.0/3.0/3.0/3.0/3.0 psi,
R-Ring : 6.0 psi, Head/Table: 87/93 rpm, Slurry : 300 ml/min

◆ SiN Finishing Slurry CMP Test Results(ST-500)



Polisher : AP-300, Pad : IC1010, W/P: 3.0/3.0/3.0/3.0/3.0 psi,
R-Ring : 6.0 psi, Head/Table: 87/93 rpm, Slurry : 300 ml/min

极思新材料 Ceria Slurry Features


Process Optimization

High-pressure Microfluidizer
Zirconia-free milling process
Separation and Filtration optimization
Impurity-free, Low LPC control




Lower Defect and Scratch

Particle surface modification
Surface zeta-potential control (+, -)
Dispersant, Stabilizer, Surfactant
Formulation optimization



Selectivity Control Pattern Performance

High selectivity for process application
Dispersant, Dishing agent, pH adjust
Skew agent, Surfactant, etc.
Chemical formation optimization







01 Introduction of CMP Slurry

Key Technology_Ceria Slurry

Confidential

◆ Introduction : Ceria Slurry Abrasive Type

Name	Conventional Slurry	极思 Slurry		
Abrasive Type	Calcined Ceria	Colloidal Type1	Colloidal Type2	Next Generation
Image				
Abrasive size	50~300nm	80~120nm	60~150nm	30nm & <10nm
shape	Non-spherical	Hexagon	Round	Hybrid

Products			Properties	Remark
Ceria-Based (Colloidal)	SDN-S4000	Low Defect/Scratch	- Ox = 2000~3000 Å/min - Ox : Nit = 1 : 25~50 / Low Dishing	Colloidal Type1
	SWC-3000	High Removal Rate	- Ox = 20K Å/min	Colloidal Type2
	SWC-5000	Super Fine Ceria	- Ox = >1K Å/min - Scratch Free	


01 Introduction of CMP Slurry

Key Technology_Ceria Slurry

Confidential

◆ Introduction : Ceria Slurry Abrasive Type

- Structure: HC60 **Crystalline**, 极思 Abrasive **Amorphous**
- Shape: HC60 **Angular Colloidal**, 极思 **Spherical Colloidal**
- Secondary Particle Size: HC60 **$100\text{nm} \pm 40\text{nm}$** , 极思 **$100\text{nm} \sim 150\text{nm} \pm 20\text{nm}$** **Size Controllable**




02 R&D Roadmap

Ceria Slurry R&D Road Map

Confidential

- **High Selectivity product line** : SDN-S4000, SDN-A4000 (Good Ox, SiN Selectivity with Chemical Additive, Low Defect)
- **High Ox Removal Product** : HRR (Advanced Product, High Removal Rate >20kÅ/min, Good Planarization)
- **Low Defect Product** : SFC (Super Fine Abrasive <10nm, Low Concentration but High Removal Rate >2kÅ/min)








02 R&D Roadmap

Defect / Scratch Improvement

Confidential


◆ Next Generation Ceria Abrasive

- Super Fine Ceria Abrasive : Uniform Shape and Size Distribution, $\text{Ce}^{3+}/\text{Ce}^{4+}$ Control based Chemical Reaction Improvement


Name	Conventional Slurry	极思 SFC Slurry			
Abrasive Type	Calcined Ceria	Present		Developing	
Image					
Abrasive size	50~300nm	80~120nm	60~160nm	25±5nm	10±5nm
Shape	Non-spherical	Hexagon	Round	Hybrid	Hybrid

◆ SFC Manufacture Process



- Abrasive synthesis method differentiation : Underwater Plasma Reaction
- Fine Membrane – Filtering Slurry for high purity



Underwater Plasma Reaction based Ceria Synthesis



Nano porous membrane filtering slurry condensation and



Transparent SFC Slurry (1wt%)

03 Major Product Portfolio

Ceria Slurry Product Portfolio

Confidential

Product			Properties	Advantages
Ceria-Based	STI/ILD	SDN-S4000 SDN-A4000	- Ox. = $>3000\text{\AA}/\text{min}$ - Nit. = $30\pm 5\text{\AA}/\text{min}$	Low Dishing & defects High Selectivity & Low Dishing
	HSS	SWC-2000	- Nitride & Poly R.R $<20\text{\AA}/\text{min}$	High selectivity Low defect levels & high yields
	HRR	SWC-3000	- OX RR $\sim 20,000\text{\AA}/\text{min}$ - Good Wafer Uniformity, Oxide Self Stop	High Oxide Removal Self Stop Slurry
	SFC	Developing	- Ox $>1000\text{\AA}/\text{min}$	Good surface quality

03 Major Product Portfolio

Major Product_SDN-S4000

Confidential


◆ Introduction : Ceria Slurry for STI CMP

- Low Dishing & colloidal ceria particle
- Multi-Selectivity (Stop on nitride or poly silicon layer)
- Nitride Stop = Selectivity 20~40 : Oxide dishing <150 Å
- Lower defectivity levels and higher yields


◆ Basic Properties & Performances

ITEM	SDN-S4000
Abrasive	Colloidal
Particle Size (DLS method)	140 nm
pH	Basic
Solid Content	3 ~5 wt%
Zeta-Potential	Negative
Metal Impurity (ppm)	≤ 10 ppm

Abrasive TEM images




◆ CMP Test Results & Selectivity



Polisher : AP-300, Pad : IC1010, W/P: 3.5/3.0/3.0/3.0/3.0 psi, R-Ring : 6.5 psi, Head/Table: 87/93 rpm, Slurry : 250 ml/min

◆ Dishing Performance



03 Major Product Portfolio

Product_SDN-S4000



Confidential

◆ Major Product: SDN-S4000

- Target: Ox R/R > 3,000 Å/min
- Low Defect & Scratch process



- Negative Wet-Ceria

- Abrasive dispersity improvement, Agglomeration suppression
- Oxide wafer Defect/Scratch controllable




- Large particle removal by improving dispersion process

- Bead-free milling dispersion (zirconia impurity free)
- High pressure microfluidizer + Separator : large particle removal




- Dispersant optimization

- Dispersant content control
→ Ox R/R Improvement
- Dispersant MW control
→ Ox CNT Profile improvement




- Defect control

- Stabilizer : Preventing particle aggregation, Uniform Size control
- Surfactant: Preventing debris aggregation from polishing process




※ Defect count 20% decrease

POR : 555ea



极思 : 110ea



03 Major Product Portfolio


Product_SDN-A4000

Confidential

◆ Major Product: SDN-A4000 (Additive for ILD Process)



- Slurry Surface-potential optimization for selectivity control

- Negative-type chemical formulation base Dishing control






- Dishing performance improvement

- Negative-type chemical - Electrostatic & Hydrophobic interaction
: Amine & Hydroxide group controllable chemical
- High & Low MW Surfactant
: Passivation density control based low dishing



◆ Dishing Performance



03 Major Product Portfolio

Product_SWC-2000

Confidential


◆ Ceria Slurry for High Selectivity

- Low Dishing & colloidal ceria particle
- Excellent PETEOS/SiN/Poly selectivity
: Nitride & Poly R.R <20Å/min
- Lower defect levels and higher yields


◆ Basic Properties & Performances

ITEM	SWC-2000
Abrasive	Colloidal
Particle Size (DLS method)	140 nm
pH	Acidic
Solid Content	3 ~ 5 wt%
Zeta-Potential	Positive
Metal Impurity (ppm)	≤ 10 ppm

Abrasive TEM images




◆ CMP Test Results & Selectivity



Polisher : AP-300, Pad : IC1010, W/P: 3.5/3.0/3.0/3.0 psi,
R-Ring : 6.5 psi, Head/Table: 87/93 rpm, Slurry : 200 ml/min

◆ Dishing Performance



03 Major Product Portfolio

Product_SWC-3000

Confidential


◆ Ceria Slurry for High R/R

- Hybrid colloidal ceria particle
- Oxide Removal Rate >20K Å/min
- Oxide Self Stop
- Dishing <200 Å


◆ Basic Properties & Performances

ITEM	SWC-3000
Abrasive	Hybrid Colloidal
Particle Size (DLS method)	100 nm
pH	Acidic
Solid Content	3 ~ 5 wt%
Zeta-Potential	Positive
Metal Impurity (ppm)	≤ 10 ppm


Abrasive TEM images



◆ CMP Test Results & Selectivity



◆ Dishing Performance





THANK YOU

极思新材料科技（无锡）有限公司